




R32 MULTI CASSETTE

SPARE PARTS LIST

August 2023

GKH(12)BB-K6DNA3A/I

Exploded View




GKH(12)BB-K6DNA3A/I

Spare Parts List

No.	Part Description	Part Code
1	Rear Grill	26909400007
2	Fan Motor	1570940000401
3	Water Tray Assy	01289400004
4	Water Pump	4313800005801
5	Supporter	N/A
6	Liquid Level Switch	450102013
7	Pump Drainpipe	26909400069
8	Water Pump Assy	15409400008
9	Right Side Plate Sub-Assy	01319400013
10	Bottom Foam Assy	12509400004
11	Base Plate Assy	02229400007
12	Body Installing Support	01332705
13	Left Side Plate Sub-Assy	01319400012
14	Press Plate (Outlet Pipe)	01349400004
15	Electric Box Assy	100002060081
16	Terminal Board	420001000002
17	Wire Clamp	71010103
18	Main Board	300002060012
19	Electric Box Cover	01429400003
20	Front Side Plate Sub-Assy	01319400014
21	Drain Hose Sub-Assy	007008000001
22	Room Sensor	39000191
23	Tube sensor	3900012128
24	Remote Controller	305100491
25	Evaporator Assy	01029400058
26	Supporter	01809400007
27	Centrifugal Fan	10429400001
28	Diversion Circle	10479400001

GKH(18)BB-K6DNA3AI SP

Exploded View




GKH(18)BB-K6DNA3AI SP

Spare Parts List

No.	Part Description	Part Code
1	Rear Grill	26909400007
2	Diversion Circle	10479400001
3	Water Tray Assy	01289400004
4	Centrifugal Fan	10429400001
5	Supporter	01809400007
6	Baffle Plate Sub-assy	01359400002
7	Liquid Level Switch	450102013
8	Pump Drainpipe	26909400069
9	Left Side Plate Sub-Assy	01319400012
10	Press Plate (Outlet Pipe)	01349400004
11	Front Side Plate Sub-Assy	01319400014
12	Capacitor CBB61	N/A
13	Terminal Board	N/A
14	Terminal Board	420001000002
15	Main Board	300002060012
16	Electric Box Assy	100002060083
17	Body Installing Support	01332705
18	Base Plate Assy	02229400007
19	Right Side Plate Sub-Assy	01319400013
20	Water Pump	4313800005801
21	Evaporator Assy	01029400013
22	Fan Motor	1570940000401
23	Remote Controller	305100491
24	Drain Hose Sub-Assy	007008000001
25	Tube sensor	3900012128
26	Room Sensor	39000191

GKH(24)BC-K6DNA4A/I

Exploded View



GKH(24)BC-K6DNA4A/I

Spare Parts List

No.	Part Description	Part Code
1	Tube Exit Plate Assy	01382715
2	Shell Assy	01432703
3	Body Installing Plate	01332701
4	Front Side Plate Assy	01302718
5	Left Side Plate Assy	01302715
6	Base Plate Assy	01222701
7	Rear Side Plate Assy	01302714
8	Bottom Foam Assy	52012722
9	Motor Gasket	76712711
10	Motor Support	N/A
11	Fan Motor	1570940000401
12	Centrifugal Fan	10312705
13	Connected Board Assy of Evaporator	01074042
14	Filter Sub-Assy	N/A
15	Drain Hose Sub-Assy	05339400001
16	Water Tray Assy	000069000104
17	Electric Base Plate	01412721
18	Diversion Circle	10372701
19	Electric Box Assy	100002060082
20	Transformer	N/A
21	Terminal Board	420001000002
22	Electric Box Cover	0142410004801A
23	Electric Box Cover Sub-Assy1	N/A
24	Temperature Sensor	390001921
25	Temperature Sensor	390000457
26	Electric Box Cover Sub-Assy2	N/A
27	Cover of Electric Box II	N/A
28	Main Board	300002060012
29	Capacitor CBB61	N/A
30	Evaporator Assy	011001060292
31	Evaporator Support Assy	01072703
32	Magnetic Ring	49010104
33	Water Pump	43138000058
34	Water Pump Assy	15409400009
35	Pump Support	N/A
36	Water Level Switch	45020216
37	Pump Drainpipe	26909400068
38	Right Side Plate Assy	01302716
39	Remote Controller	305100491
40	Pump Cover Board Assy	01252713
41	Display Board	N/A

It is the policy of Gree Australia to introduce continuous product improvements.
Accordingly, specifications are subject to change without notice.
Please consult with your dealer to confirm the specifications of the model selected.

1800 473 346
greeac.com.au

